





Mast Mount

For help & information
 email: technical@scanstrut.com
 tel: +44 (0) 1803 863800



	A* mm / inches	B mm / inches	C mm / inches	D mm / inches
SC16	65/2.6	400/15.8	198/7.9	95/3.7
SC20	65/2.6	460/18.1	268/10.6	95/3.7
SC21	65/2.6	520/20.5	278/10.9	125/4.9
M92722	65/2.6	467/18.4	278/10.9	95/3.7
M92698	76/3	530/20.8	300/11.8	180.8/4.9

	W* mm / inches	X mm / inches	Y mm / inches	Z mm / inches
SC12	77/3	351/13.8	185/7.5	110/4.3
SC18	72/2.8	311/12.2	85/7.3	92/3.6

* indicates minimum mast width, no maximum mast width exists.

** 50100 Adapter kit will be required for Z-Spars, Eurospars and Isomat masts



SCANSTRUT[®]
 INSTALLATION SOLUTIONS FOR MARINE ELECTRONICS[™]